

v2.0

# SANDBLASTING & PREPARING HALFTONE PHOTOS

#### Introduction

These notes will take you through the process of preparing a photograph for sand blasting; it will then go through the correct steps for sandblasting the halftone.

Before starting we need to consider one important rule. "The bigger, the better!" This applies to both the original photo that you're working from, and the size of the final sandblasted image. Small photos can be done, but the larger you can make it the better it will be to work with and the better the final product will look.

In order to sandblast a photo consisting of many different tones, shades and colours we must convert it into a half tone image. Halftone artwork is used to reproduce grayscale images by breaking the image into small dots (like photos in the newspaper). These dots will vary in size to represent the tonal areas of the artwork, giving the illusion of a grayscale image.

#### **Required Elements**

To create good results when blasting half tone photos use **SR3000 3mil** self stick resist. You will need to have a copy of **Adobe Photoshop** (or Corel PhotoPaint, however this proceedure uses Photoshop) to make the necessary adjustments and conversions. For best results you will also need to print your artwork onto **LaserFilm™** or **InkJet Film** instead of normal vellum paper. These films have a higher level of transparency and allow superior exposure onto the SR3000 resist.

It is very important to get a quality exposure onto the SR3000 to ensure the entire image comes out at the highest possible quality. The best exposure unit to use for producing half tone photo resists is the **26-1KS NuArc® U.V. Exposure System**, this a built-in vacuum system to create exact exposures of every little dot. However if you do not have one of the NuArc systems, the **Letralite** exposure lamp can also be used. When using the Letralite make sure the acrylic tube is clean from specks and the black rubber mat is not too stretched and loose around the tube. Having even a slightly loose mat around your exposure can greatly affect the consistency of your final result. It may be necessary to purchase a new tight rubber mat for the Letralite if yours is too old and causing exposure issues.

### Photo Preparation

It is important to start with a good high quality image, the lower the quality of the photo the more work and time you will have to spend on touching it up in Photoshop. Standard printing resolution is 300dpi. 300dpi and anything over is ideally what you want when your going to sandblast as a half tone. The most common way to receive a photo from a client is via email. Digital photos are usually 72dpi, which means you will need to adjust them a fair bit. If it is possible, get the client to provide a physical print of the photo for you to scan at a nice high resolution (300dpi or 600dpi). Once you have your photo in a digital format open the photo in Photoshop. Now you need to establish what size the image needs to be on the final job. You may need to measure the physical area. When you have

	Same:	Uneflud-1			0.
peat 0	uton		1	-	keset
	1, 120				Save Preset.
	With	150	mm		Coleta Presen
	HOURS:	210	onm	*	Contract Contract
- 33	polutor:	300	prakinch	*	Ligica centra
0	dor Mode:	Gayscale	- obt	9	
ackground Contents: White					Second Second

these measurements, create a new document in Photoshop to the appropriate size with a resolution of 300dpi and colours set to grayscale. **(see fig.1)** 

Now drag your image onto the new blank canvas. Once you've got your image on the new canvas, use the Free Transform tool **(Ctrl + T)** to adjust the image size by dragging the corners with the **Shift** key held down. Get your image positioned where you want it on the canvas then use the Rectangular Marquee Tool to select the entire canvas at it's edges. Now that there is a dashed line is moving around the image go to the **'Image'** menu and select **'Crop'**.



v2.0

### SANDBLASTING & PREPARING HALFTONE PHOTOS. (continued)

#### Photo Preparation (continued)

Now that your image is the correct size and in grayscale. We are ready to start adjusting the photo for the half tone conversion. This is the most important part of the process. Preparing the image correctly ensures a high quality realistic half tone. First we must decide if the background of the image is suitable. If it is too complicated or not important and detracting from the subject separate the subject from the background. There are many ways to achieve this in Photoshop. If the subject has a hairy or furry edge, a good technique is the **'Extract'** tool in the **'Filter'** menu. To use this simply outline the image with the highlighter tool in the subject. **(see fig.2)** 

Now use the masking tool <sup>[16]</sup> to clean up the edges around your subject **(see fig.3)**. Clicking will erase with this tool and clicking while holding **'Alt'** will restore image. Its a good idea to spend a little time getting a good clean edge.

(see fig.4).







fig.4



Now that we have the subject free from the background. It's time to put a simple more suitable background in. There are two options for simple backgrounds, depending on what suits the image/job. The first is simply a 20% black (see fig.5). To achieve this create a new layer and make it completely black then pull back the 'Fill' in the 'Layers' palette to 20%. The other option is a simple cloud background (see fig.6). To do this create a new layer and select 'Filter' then 'Render' then 'Clouds', keep re-applying the filter until you have a background that you like.



fig.6





v2.0

### SANDBLASTING & PREPARING HALFTONE PHOTOS. (continued)

Photo Preparation (continued)

The next step to preparing the photo for half tone conversion is to level out the brightness and contrast. First select the subjects layer, then in the 'Image' menu got to 'Adjustments' then 'Levels', Bring the sliders towards each other a little bit to bring out the detail in the subject, and move the middle slider to make the whole image lighter. Now we use the 'Clone Stamp' tool . The idea here is to eliminate any vast differences in contrast. Hold 'Alt' while over a suitable tonal area.

Then with the **'Opacity'** in the top tool bar set to about **45%**, level out any very bright areas and shines. Do the same with areas that are too dark by selecting a lighter tone with the clone stamp. You may also like to use the **'Dodge'** and **'Burn' Dodge Tool** tools to lighten and darken problem areas.



It is extremely important to get the whites of the eyes and teeth bright enough. The more time you spend getting your photo to the right levels the better and more realistic your half tone will look on the end product. It is a good idea to save your image at this stage so you can go back to it if there are still problem areas during washout. It's a good idea to do a test at this stage so you can do any fine tuning of too light and too dark areas.

### Converting to the Half Tone

Pure white areas generally don't look good when sandblasted. To compensate for this we will limit our image to 90% of pure white. Open the Levels control panel (Ctrl+L) and set the Output Levels to O and 23O (see fig.7). Once this is completed, make sure the image is selected and go to 'Image' then 'Mode' then 'Bitmap'. Set the output to 300ppi and the method to 'Halftone Screen' (see fig.8). Set the half tone settings to 'Frequency 45', 'Angle 45' and 'Shape Ellipse' (see fig.9).



Now that your image is a half tone you are almost complete. But before we print and sand blast we must 'Invert' the image to create a negative. Do this by selecting the image and going to the 'Image' menu, 'Adjustments' then 'Invert' (see fig.10).

When satisfied with the results of your test print, output your image by printing it onto your LaserFilm, InkJet Film or Vellum (if you have no other out media). When you are forced to use Vellum paper as your transfer media, the first thing is changing the line screen **'Frequency'** to **30** you definitly want a much larger dot for a vellum print





fig.8	Bitmap	
age e no your <b>ncy'</b>	Resolution Input: 300 pixels/inch Qutput: 300 pixels/inch v Method Use: Halftone Screen v Custom Pattern: v	OK Cancel
fig.9	Halftone Screen  Halftone Screen  Erequency: 45  Angle: 45  degrees  Shape: Ellipse	OK Cancel Load Save



v2.0

## SANDBLASTING & PREPARING HALFTONE PHOTOS. (continued)

### Sandblasting the Half Tone

It is important to apply 'Magic Dark' (tonal repair kit) on your printed art, expecially when Vellum is being used. Spray an even amount over your printed halftone and roll off any eccess with the rolling wand. Once you have allowed this to dry it is time to expose your halftone. Expose the film negative with SR3000<sup>™</sup> 3 mil photos resist film (20 seconds with the Letralite UV exposure lamp). If you are using a Letralite make sure your black rubber mat is nice and tight against the clear tube. If there is any slack in your mat you may have trouble getting a good exsposure. This will cause all sorts of problems, so if your mat is loose we strongly recommend replacing it before attemping a half tone photo. Wash out as normal, warm water (about shower temperature) will give best and quickest results. Be very careful not to over wash and try to wash it out as quickly as possible. Allow your resist to dry.

Clean the surface of the item with an appropriate cleaner. In colder weather we recommend you slightly warm the item. Apply mask and transfer carefully with a plastic burnisher and then roll with wire wheel brush. It is also very important to get a good even bond between the SR3000 mask and the object. If for some reason the SR3000 loses some of it's tackiness, try quickly placing the resist face down on a damp cloth or blotting towel just to slightly moisten the surface. This reactivates the self stick properties of the resist and will allow a strong and even bond.

While blasting, go over the entire area of the photo using a small circular blasting pattern in lines across the image and work your way over the entire artwork. You should be blasting at between 20 - 25psi when etching half tones , and always make sure your nozzel is perpendicular to the product. When the clear membrane blasts away completely the area has been sufficiently etched.

Remove the mask entirely or if paint filling is required, lightly coat with a light coloured spray paint. Allow to dry and remove mask.

### Summary Sheet

- Scan Photo at 300 600dpi (if required).
- Resize and convert image to graysclae.
- Remove background (if required).
- Adjust levels and prepare photo (paying special attention to eyes and teeth).
- Save a copy for possible fine tuning.
- Perform half tone conversion.
- Invert image.
- Test print. Then perform any fine tuning to tone and levels on saved photo (if required).
- Output to LaserFilm or InkJet film.
- Expose and washout. Allow to dry.
- Apply resist mask to object.
- Burnish.
- Sand blast.
- Clean Up.
- Enjoy!